



NOTES:

1. SAMPLING TAPS SHALL USE STANDARD SERVICE TAPS IF AVAILABLE, OTHERWISE INSTALL THIS AT ENDS OF LINE OR AS DIRECTED BY THE ENGINEER.
2. SAMPLING TAP TO REMAIN AND BE REMOVED BY CITY.
3. BEYOND TRAVEL LANES EXTEND 18" MIN. ABOVE GRADE.
4. IF SADDLE IS REQUIRED BY ENGINEER, USE BRASS TYPE.

WOODBURN
 O R E G O N
Incorporated 1889
 PUBLIC WORKS DEPARTMENT
 ENGINEERING DIVISION

**SAMPLING TAP
 ASSEMBLY**

REV: DEC. 2007

SCALE: NTS

DET No.

5100-1